

# Splice Kits for CORFLEX\* II Cables

Materials for a 600/1000 volt kit should include:

- Suitable compression connector for copper or aluminum conductors
- Cleaning fluid
- Sandcloth
- Scotch 130C splicing tape
- Scotch No. 33 vinyl plastic tape
- Tinned copper braid straps
- Hose clamps
- Heat shrink tube
- Installation instructions

## Typical Single Conductor CORFLEX Splice

